

diy ipod nano case

instructions:

- 1. cut on solid lines.
- 2. fold on dotted lines.

tips:

- use a ruler.
- exactos work better than scissors.
- trace the dotted lines with a pen and ruler for straight clean folds.
- scroll wheel is approx. size of a soda cap.
- be a good person.
- fit a piece of packing tape on both sides of front for functional, protective windows.
- feel free to hack/modify/tweak.
- recycle your waste: use as a template on everday items .

